

robosen
THE ROBOT COMPANY



TRANSFORMERS and HASBRO and all related trademarks and logos are trademarks of Hasbro, Inc.
© 2026 Hasbro.

© TOMY 「トランスフォーマー」、「TRANSFORMERS」は株式会社タカラトミーの登録商標です。








robosen
THE ROBOT COMPANY

QUICK START GUIDE

Soundwave







Hi, Soundwave / Hey, Soundwave / All hail Decepticons

Convert	Introduce yourself	Hello	Merry Christmas	Start Voice Programming	Turn It Up
Move Forward	What can you do	Report	Happy Halloween	Execute	Max Volume
Move Backward	Optimus Prime	Defense	Happy Thanksgiving	Cancel	Turn It Down
Turn Left	Decepticons	Retreat	Happy Valentine's Day	Start Easy Programming	Mute
Turn Right	Laserbeak	Energon	Happy April Fool's Day	Play	Shutdown
Move Left	Cybertron	Mission	Happy Birthday	Show	
Move Right	Ravage	Detect	Happy Holiday	Next	
Turn Around	Autobot	Attack	Happy New Year		
	Galvatron	Earth			
	Megatron	Open Fire			



嗨，声波/嘿，声波/霸天虎万岁！

变形	自我介绍	你好	生日快乐	开始语音编程	增大音量
前进	你会什么	报告	节日快乐	执行	声音最大
后退	擎天柱	防御	新年快乐	取消	减小音量
左转	霸天虎	撤退	情人节快乐	开始简易编程	静音
右转	激光鸟	能量块	愚人节快乐	播放	关机
左移	赛博坦	任务	圣诞节快乐	表演一下	
右移	机器狗	探测	万圣节快乐	下一个	
转身	汽车人	攻击	感恩节快乐		
	惊破天	地球			
	威震天	开火			

(Global)



(Global)



Robosen Soundwave G1



(中国大陆地区专用)


乐森声波G1









①




②



③




④






①

Recording Mode
进入录音模式




②

Speak after the beep
听到滴的一声后开始录音




③

Recording Saved
录音已保存







④



⑤



Recording Mode Off
退出录音模式



Programming Tutorial
(English Version)



编程教程
(中文版)



www.robosen.com/support 

www.robosen.cn/support 

 robosen乐森机器人

 www.robosen.com

 support@robosen.com