







































Engin Bot 1S 零件清单

	x10		x4		x60		x30		x28		x12		x20		x2		x12		x4		x28		x12		x4
	x4		x4		x10		x5		x2		x2		x2		x8		x6		x2		x2		x1		x4
	x4		x4		x4		x4		x4		x4		x4		x1		x1		x2		x2		x5		x5
	x5		x8		x10		x20		x10		x6		x6		x5		x5		x2		x2		x2		x2
	x1		x2		x2		x2		x1		x2		x1		x2		x2		x2		x1		x2		x2
	x3		x1		x1		x1		x1		x1		x1		x1		x6		x1						