



Installation video guide

Scan the QR code on the right and follow the video instructions to install it.




Download the ANTHBOT App

ANTHBOT App can be downloaded from Apple APP Store or Google Play, or scan the QR code to download and install ANTHBOT App. After downloading, please register an account, log in and follow the APP prompts to add the device to start using.



Step 1 Find location

1 Find an unobstructed area




Warning: Ensure the installation location has WiFi signal coverage.

2 Place charging station




Step 2 Installation

Installation and power supply




4 Check signal lights

After connecting the charging station to the power supply, verify that the RTK signal indicator is solid green.





Warning: The indicator light cannot stay green all the time. Please try again after changing the installation location.

Place the machine on the charging station and turn it on. If the GPS indicator is solid (this may take approximately 3 minutes), the location meets the installation requirements.




5 Secure the charging station



Step 3 Operation


App operation



Warning :

1. Please create a map before starting the task.
2. Before operation, please ensure that the RTK base station indicator is solid green and that the GPS signal indicator on the machine is solid.
3. Make sure to start from the charging station before creating a map.
4. If the RTK base station is tilted or moved after the map is created, you need to recreate the map.
5. Please create the No - go Zone in the application to prevent the device from entering the dangerous area.

Mower operation



User manual
Please refer to the user manual for more details



Welcome to join our Facebook Group for a discussion

